

Non - Korea

System	Sub System	System Info.	Read-clear Dtc.	Data stream	Actuation	Air bleed	Impact Info.	Else
KIA PRIDE								
Engine(~98,99,02,03,04)	1.3L SOHC gasoline FBC before 1998		<i>err. Code</i>					
	1.3L SOHC gasoline AFM1 before 1998		<i>err. Code</i>					
	1.3L SOHC GASOLINE MAP		<i>err. Code</i>	<i>data</i>				
AT(2002,03,04)			<i>err. Code</i>	<i>data</i>				
KIA VISTO								
Engine(ALL Year)	UNLEAD ALL		<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
	UNLEAD IMMO		<i>err. Code</i>	<i>data</i>	√			
	LEAD ALL		<i>err. Code</i>	<i>data</i>	√			2.RESETTING ADAPTIVE VALUES
AT(All Year)			<i>err. Code</i>	<i>data</i>	√			
ABS(All Year)			<i>err. Code</i>	<i>data</i>	√	√		
SRS(All Year)			<i>err. Code</i>	<i>data</i>				
KIA AVELLA								
Engine(ALL Year)	1.3/1.5 GASOLINE MAP		<i>err. Code</i>	<i>data</i>				
AT			<i>err. Code</i>					
ABS			<i>err. Code</i>	<i>data</i>				
KIA RIO								
Engine(2007 -08)	1.6L CVVT EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
	1.6L CVVT GEN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
	1.6L CVVT LEAD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
	1.4L DOHC EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES

	1.4L DOHC GEN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
	1.4L DOHC LEAD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
	1.5L VGT DIESEL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			01.INJECTOR CORRECTION 02.ENGINE TEST FUNCTION
Engine(2000 -06)	1.6 CVVT(2006)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
	1.4 DOHC(2006)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
	U 1.5L VGT DIESEL(2006)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			01.INJECTOR CORRECTION 02.ENGINE TEST FUNCTION
	1.3/1.5 GASOLINE MAP		<i>err. Code</i>	<i>data</i>				
	1.3/1.5L MAF		<i>err. Code</i>	<i>data</i>				
	1.3/1.5L (RHD) MAP		<i>err. Code</i>	<i>data</i>				
	1.3/1.5L (RHD) MAF		<i>err. Code</i>	<i>data</i>				
	1.3/1.5L GASOLINE /IMMO		<i>err. Code</i>	<i>data</i>				
	1.3/1.5L GASOLINE LEAD		<i>err. Code</i>	<i>data</i>				
AT(2007-08)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
AT(2000-06)	CAN BUS(2006)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	TCU LHD		<i>err. Code</i>	<i>data</i>				
	TCU RHD		<i>err. Code</i>	<i>data</i>				
ABS	ABS(2007-08)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
	ABS (2006)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
	DLC CABLE 16 (2003-05)		<i>err. Code</i>	<i>data</i>	√	√		
	20PIN RED KIA CONNECTOR (2003-05)		<i>err. Code</i>	<i>data</i>	√	√		
	ABS LHD (2000 -02)		<i>err. Code</i>	<i>data</i>	√			
	ABS RHD (2000 -02)		<i>err. Code</i>	<i>data</i>	√			
SRS	SRS (2007-08)	<i>Info</i>	<i>err. Code</i>					
	SRS (2006)	<i>Info</i>	<i>err. Code</i>				√	
	A/BAG LHD(2000 -05)		<i>err. Code</i>					
	A/BAG RHD(2000 -05)		<i>err. Code</i>					

IMMIBILIZER	IMM(2006~2008)			<i>data</i>				01.PASSWORD TEACHING/CHANGING 02.TEACHING 03.NEUTRAL MODE 04.LIMP HOME MODE
ELEC. POWER STEERING(2006~ 2007)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
KIA SEPHIA (MENTOR)								
Engine	1.6L DOHC NON IMMO (2001-04)		<i>err. Code</i>	<i>data</i>				
	1.6L DOHC W/IMMO (2001 -04)		<i>err. Code</i>	<i>data</i>				
	1.6L DOHC LEAD (2001 -04)		<i>err. Code</i>	<i>data</i>				
	1.8L DOHC GASOLINE TED (1998-2004)		<i>err. Code</i>	<i>data</i>				
	1.5L GASOLINE BFD/BFE (1998-2000)		<i>err. Code</i>	<i>data</i>				
	1.5/1.6L ENG(MTM) AFM1 (before 1998)		<i>err. Code</i>					

	1.5/1.6L ENG(ATM) AFM1 (before 1998)		<i>err. Code</i>					
	1.5 GASOLINE MAP		<i>err. Code</i>	<i>data</i>				
AT	(1998-2004)		<i>err. Code</i>	<i>data</i>				
	before 1998		<i>err. Code</i>					
ABS(1998-2004)			<i>err. Code</i>	<i>data</i>	v			
SRS(before 1998 - 2004)			<i>err. Code</i>					
KIA SHUMA								
Engine	1.6L DOHC NON IMMO (2001-04)		<i>err. Code</i>	<i>data</i>				
	1.6L DOHC W/IMMO (2001 -04)		<i>err. Code</i>	<i>data</i>				
	1.6L DOHC LEAD (2001-04)		<i>err. Code</i>	<i>data</i>				
	1.8L DOHC GASOLINE TED (1999-2004)		<i>err. Code</i>	<i>data</i>				
	1.5L GASOLINE BFD/BFE (1999-2000)		<i>err. Code</i>	<i>data</i>				

AT(1999-2004)			<i>err. Code</i>	<i>data</i>				
ABS(1999-2004)			<i>err. Code</i>	<i>data</i>	√	√		
SRS(1999-2004)			<i>err. Code</i>					
KIA CARENS								
Engine	LEAD 2.4L ALL(2007~2009)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES 2.FREEZE FRAME DATA
	UNLEAD 2.4L GEN(2007~2009)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES 2.FREEZE FRAME DATA
	UNLEAD 2.4L EOBD(2007~2009)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES 2.FREEZE FRAME DATA
	LEAD 2.0L ALL(2007~2009)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES 2.FREEZE FRAME DATA
	UNLEAD 2.0L GEN(2007~2009)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES 2.FREEZE FRAME DATA

UNLEAD 2.0L EOBD(2007~2009)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES 2.FREEZE FRAME DATA
2.0L DIESEL(KWP) EURO - 4(2007~2009)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.CPF SERVICE REGENERATION 2.INJECTOR CORRECTION 3.COMPONENT CHANGE ROUTINE 4.ENGINE TEST FUNCTION
2.0L DIESEL(CAN)(2007~2009)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.CPF SERVICE REGENERATION 2.INJECTOR CORRECTION 3.COMPONENT CHANGE ROUTINE 4.ENGINE TEST FUNCTION
2.0L DIESEL(CAN) EURO -4(2006)		<i>err. Code</i>					1.CPF SERVICE REGENERATION 2.INJECTOR CORRECTION 3.COMPONENT CHANGE ROUTINE 5.ENGINE TEST FUNCTION

2.0L DIESEL(KWP) EURO-4(2006)		<i>err. Code</i>					1.CPF SERVICE REGENERATION 2.INJECTOR CORRECTION 3.COMPONENT CHANGE ROUTINE 6.ENGINE TEST FUNCTION
2.0L/2.4L GASOLINE(2007)		<i>err. Code</i>					
2.0L CVVT ALL (2004-06)		<i>err. Code</i>	<i>data</i>	√			1.RESTTING ADAPTIVE VALUES 2.VERSION CONFIGURATION
1.8L LPG (2004-05)		<i>err. Code</i>	<i>data</i>	√			
2.0L LPG (2004-05)		<i>err. Code</i>	<i>data</i>	√			
2.0L DIESEL (2003-06)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.ENGINE TEST FUNCTION
1.6L DOHC W/IMMO (2003-05)		<i>err. Code</i>	<i>data</i>				
1.6L DOHC EURO -IV (2003-05)		<i>err. Code</i>	<i>data</i>				
1.8L DOHC NON IMMO (2003-05)		<i>err. Code</i>	<i>data</i>				

	1.8L DOHC W/IMMO (2003 -05)		<i>err. Code</i>	<i>data</i>				
	1.8L DOHC EURO -IV (2003-05)		<i>err. Code</i>	<i>data</i>				
	1.8L DOHC LEAD (2003-05)		<i>err. Code</i>	<i>data</i>				
	1.8L DOHC M/T (2001-02)		<i>err. Code</i>	<i>data</i>				
	1.8L DOHC (2001-02)		<i>err. Code</i>	<i>data</i>				
	1.8L DOHC GASOLINE TED (1999-2000)		<i>err. Code</i>	<i>data</i>				
AT	DIESEL (2003 -05)		<i>err. Code</i>	<i>data</i>	√			
	GASOLINE (1999 -2005)		<i>err. Code</i>	<i>data</i>				
	1.8L LPG (2004-2005)		<i>err. Code</i>	<i>data</i>				
	2.0L LPG (2004-2005)		<i>err. Code</i>	<i>data</i>	√			
	2 007		<i>err. Code</i>					
	2.0/2.4 SIEMENS(2007~2009)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.CPF SERVICE REGENERATION

	2.0L DIESEL(VET) EURO - 4(2007~2009)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.CPF SERVICE REGENERATION
ABS	DLC CABLE 16 (2003-05)	<i>Info</i>	<i>err. Code</i>			√		
	20PIN RED KIA CONNECTOR (2003-05)	<i>Info</i>	<i>err. Code</i>					
	1999-2002		<i>err. Code</i>	<i>data</i>	√			
	2 006		<i>err. Code</i>	<i>data</i>	√	√		
	2007~2009	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
SRS	2003-2005	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	1999-2002 2007	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	2007~2009	<i>Info</i>	<i>err. Code</i>					1.PASS.AIRBAG REALTIME INFO. 2.CRASHING INFORMATION
A/C	2 007	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	2007~2009	<i>Info</i>	<i>err. Code</i>		√			

IMMIBILIZER	2003~2009			<i>data</i>				01.SMARTRA NEUTRAL 02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.NEUTRAL MODE 05.LIMP HOME MODE
BCM	2007~2009	<i>Info</i>		<i>data</i>	√			
KIA SPORTAGE								
Engine	2.0L DIESEL(CAN) EURO-4(07~08)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.CPF SERVICE REGENERATION 2.INJECTOR CORRECTION 3.COMPONENT CHANGE ROUTINE 4.ENGINE TEST FUNCTION
	2.0L DIESEL(CAN) EURO -4(06)		<i>err. Code</i>					1.CPF SERVICE REGENERATION 2.INJECTOR CORRECTION 3.COMPONENT CHANGE ROUTINE 4.ENGINE TEST FUNCTION

2.0L DIESEL(KWP) EURO-4(07~08)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√				1.CPF SERVICE REGENERATION 2.INJECTOR CORRECTION 3.COMPONENT CHANGE ROUTINE 4.ENGINE TEST FUNCTION
2.0L DIESEL(KWP) EURO -4(06)		<i>err. Code</i>						1.CPF SERVICE REGENERATION 2.INJECTOR CORRECTION 3.COMPONENT CHANGE ROUTINE 4.ENGINE TEST FUNCTION
2.0L DIESEL EURO -3 (07-08)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√				1.ENGINE TEST FUNCTION
2.0L DIESEL ALL (2004 -2006)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√				1.ENGINE TEST FUNCTION
2.0L CVVT EOBD (2004 -2008)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√				1.RESETTING ADAPTIVE VALUES 2.VERSION CONFIGUTRATION

2.0L CVVT GEN (2004-2008)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	v				1.RESETTING ADAPTIVE VALUES 2.VERSION CONFIGUTRATION
2.0L CVVT LEAD (2004-2008)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	v				1.RESETTING ADAPTIVE VALUES 2.VERSION CONFIGUTRATION 3.IDLE CO ADJUSTMENT
2.7L V6 EOBD (2004-2008)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	v				1.RESETTING ADAPTIVE VALUES 2.VERSION CONFIGUTRATION
2.7L V6 GEN (2004-2008)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	v				1.RESETTING ADAPTIVE VALUES 2.VERSION CONFIGUTRATION
2.7L V6 LEAD (2004-2008)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	v				1.RESETTING ADAPTIVE VALUES 2.VERSION CONFIGUTRATION 3.IDLE CO ADJUSTMENT

	2.0L DOHC(HFM) BOSCH (2001-03)		<i>err. Code</i>	<i>data</i>				
	2.0L DOHC(HFM) LEAD (1998-2003)		<i>err. Code</i>	<i>data</i>	√			
	2.0L DIESEL RF -TCI (1998-2003)		<i>err. Code</i>	<i>data</i>	√			
	2.0L GASOLINE (before 1998)		<i>err. Code</i>	<i>data</i>	√			
	2.0L Diesel RF -TCI (before 1998)		<i>err. Code</i>					
	2.0L DOHC(HFM) UNLEAD (1998-2000)		<i>err. Code</i>	<i>data</i>				
	UNLEAD(AUS) (2000)		<i>err. Code</i>	<i>data</i>				
AT	2.0L DIESEL(VGT) EURO -4(06)		<i>err. Code</i>					
	2.0L DIESEL(VGT) EURO-4(07~08)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	2.0L DIESEL/2.7L GASOLINE(2004-2008)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

	2.0L GASOLINE(PCM) (2004-2008)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	(1998,99,01)		<i>err. Code</i>	<i>data</i>				
	TCU GASOLINE (2002,03)		<i>err. Code</i>	<i>data</i>				
	TCU DIESEL (2002,03)		<i>err. Code</i>	<i>data</i>				
	GASOLINE/DIESEL (2000)		<i>err. Code</i>	<i>data</i>				
	UNLEAD(AUS) (2000)		<i>err. Code</i>	<i>data</i>				
	before 1998		<i>err. Code</i>					
ABS	ABS/TCS/ESP (2007 -2008)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
	ABS/TCS/ESP (2004 -2006)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
	ABS GASOLINE (2001 -03)		<i>err. Code</i>	<i>data</i>	√	√		
	ABS DIESEL (2001 -03)		<i>err. Code</i>	<i>data</i>	√	√		
SRS	SRS AIRBAG ETC(08)	<i>Info</i>	<i>err. Code</i>	<i>data</i>				1.PASS.AIRBAG REALTIME INFO.
	SRS AIRBAG CHINA(08)	<i>Info</i>	<i>err. Code</i>	<i>data</i>				

	SRS AIRBAG(07)	Info	err. Code	data				
	2004-2006	Info	err. Code				√	
A/C	2004-2008	Info	err. Code	data	√			
4WD	2004-2008	Info	err. Code					
IMMIBILIZER	2004-2008			data				01.SMARTRA NEUTRAL 02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.NEUTRAL MODE 05.LIMP HOME MODE
BCM	(2007-2008)	Info		data	√			
KIA CLARUS								
Engine	1.8L GASOLINE (before 1998-2000)		err. Code	data	√			
	2.0L GASOLINE (before 1998-2000)		err. Code	data	√			
AT	(1998-2000)		err. Code	data				
	before 1998		err. Code					

ABS(1998-2000)			<i>err. Code</i>	<i>data</i>	√			
SRS(up to 2000)			<i>err. Code</i>					
KIA OPTIMA 2009 (Magentis)								
Engine control	01. 2.0L DIESEL(VGT) EURO -4	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.CPF SERVICE REGENERATION 2.INJECTOR CORRECTION 3.COMPONENT CHANGE ROUTINE 4.ENGINE TEST FUNCTION
	02. UNLEAD 2.0L(NON ETC) GEN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	03. UNLEAD 2.0L(NON ETC) EOB	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	04. LEAD 2.0L(NON ETC) ALL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	05. UNLEAD 2.4L(ETC) GEN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	07. LEAD 2.4L(ETC) ALL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

	08. UNLEAD 2.7L EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	09. UNLEAD 2.7L GEN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	10. LEAD 2.7L ALL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
Automatic	01. 2.0L DIESEL(VGT) EURO -4	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
Transaxle	02. 2.4L CVVT	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	03. 2.0L CVVT	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	04. 2.7L CVVT	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
ABS/ESP		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
SRS-AIRBAG SMART KEY SYSTEM		<i>Info</i>	<i>err. Code</i>					
	03. PDM DIAGNOSTIC MODE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
FULL AUTO AIR/CON.		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

IMMIBILIZER				<i>data</i>				01.SMARTRA NEUTRAL 02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.NEUTRAL MODE 05.LIMP HOME MODE
ELEC.CONTROL SUSPENSION			<i>err. Code</i>	<i>data</i>	√			
KIA OPTIMA 2007-2008 (Magentis)								
	01. 2.0L DIESEL(VGT) EURO -4	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.CPF SERVICE REGENERATION 2.INJECTOR CORRECTION 3.COMPONENT CHANGE ROUTINE 4.ENGINE TEST FUNCTION
	02. UNLEAD 2.0L EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUS 2.VERSION CONFIGURATION
	03. UNLEAD 2.0L GEN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUS 2.VERSION CONFIGURATION

ENGINE CONTROL	04. LEAD 2.0L ALL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUS 2.VERSION CONFIGURATION
	05. UNLEAD 2.4L EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUS 2.VERSION CONFIGURATION
	06. UNLEAD 2.7L EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	07. UNLEAD 2.7L GEN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	08. LEAD 2.7L ALL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
AUTOMATIC TRANSAXLE	01. 2.0L DIESEL(VGT) EURO -4	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	02. 2.0L CVVT	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	03. 2.4L CVVT	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	04. 2.7L CVVT	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

ABS/ESP		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
SRS-AIRBAG		<i>Info</i>	<i>err. Code</i>					
IMMIBILIZER				<i>data</i>				01.SMARTRA NEUTRAL 02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.NEUTRAL MODE 05.LIMP HOME MODE
FULL AUTO AIR/CON.		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
ELEC.CONTROL SUSPENSION			<i>err. Code</i>	<i>data</i>	√			
KIA OPTIMA (MAGENTIS)								
	2.0L DIESEL(VGT) EURO-4(06-07)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.CPF SERVICE REGENERATION 2.INJECTOR CORRECTION 3.COMPONENT CHANGE ROUTINE 4.ENGINE TEST FUNCTION
	UNLEAD 2.0L EOBD(06 -07)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUS 2.VERSION CONFIGURATION

Engine	UNLEAD 2.0L GEN(06-07)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUS 2.VERSION CONFIGURATION
	LEAD 2.0L ALL(06-07)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUS 2.VERSION CONFIGURATION
	UNLEAD 2.4L EOBD(06-07)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUS 2.VERSION CONFIGURATION
	UNLEAD 2.7L EOBD(06-07)		<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	UNLEAD 2.7L GEN(06-07)		<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	LEAD 2.7L ALL(06-07)		<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	2.7L V6 GASOLINE (2002 -05)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUS 2.VERSION CONFIGURATION

2.5L V6(TIO2) EURO -III (2003-05)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√				1.RESETTING ADAPTIVE VALUS 2.VERSION CONFIGURATION
2.5L V6(ZRO2) EURO -II (2003-05)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√				1.RESETTING ADAPTIVE VALUS 2.VERSION CONFIGURATION
2.5L V6 GENERAL (2000-05)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√				1.RESETTING ADAPTIVE VALUS 2.VERSION CONFIGURATION
2.5L V6 LEAD (2000-05)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√				1.RESETTING ADAPTIVE VALUS 2.VERSION CONFIGURATION
2.4L DOHC MELCO (2000-04)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√				
2.0L DOHC A/T MELCO (2000-04)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√				
2.0L DOHC A/T LEAD (2000 -04)		<i>err. Code</i>	<i>data</i>	√				
2.0L DOHC M/T MELCO (2000-04)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√				

	2.0L DOHC M/T LEAD (2000 -04)		<i>err. Code</i>	<i>data</i>	√			
	1.8L DOHC SIEMENS(2004)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	2.0L LPG SILIUSI(2004)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	2.0L LPG BETA(2004)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	2.5L V6 EURO-III (2000-02)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUS 2.VERSION CONFIGURATION
AT(2000-07)	2.0L DIESEL(VGT)		<i>err. Code</i>					
	2.0L CVVT(06-07)		<i>err. Code</i>					
	2.4L CVVT(06-07)		<i>err. Code</i>					
	2.7L CVVT(06-07)		<i>err. Code</i>					
	TCU FOR 2.5L/2.7L GASOLINE		<i>err. Code</i>					
	TCU FOR 2.4L GASOLINE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	TCU FOR 2.0L GASOLINE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

	CVT	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	1.8/2.5 SIEMENS REGAL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
ABS(2000-07)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
SRS(2000-07)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
IMMIBILIZER	2 006			<i>data</i>				01.SMARTRA NEUTRAL 02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.NEUTRAL MODE 05.LIMP HOME MODE
A/C(2006-07)			<i>err. Code</i>					
ELEC. CONTROL SUSPENSION(200 6-07)			<i>err. Code</i>					
KIA ELAN								
Engine(1997 -98)			<i>err. Code</i>	<i>data</i>	√			
SRS(1997-98)			<i>err. Code</i>					
KIA POTENTIA								

Engine(All Year)	2.0L DOHC(HFM) UNLEAD		<i>err. Code</i>	<i>data</i>				
	2.0L DOHC(HFM) LEAD		<i>err. Code</i>					
AT			<i>err. Code</i>					
ABS			<i>err. Code</i>	<i>data</i>				
KIA ENTERPRIS								
Engine(All Year)	2.5L GASOLINE J5D		<i>err. Code</i>	<i>data</i>				
	3.0L GASOLINE JED		<i>err. Code</i>	<i>data</i>				
	OBD-II 98-99MY		<i>err. Code</i>	<i>data</i>				
AT(All Year)			<i>err. Code</i>					
ABS(All Year)	3.0L GASOLINE JED		<i>err. Code</i>	<i>data</i>				
	3.6L GASOLINE J6D		<i>err. Code</i>	<i>data</i>				
SRS(All Year)			<i>err. Code</i>					
KIA CARNIVAL (SEDONA)								
	2.7/3.8L GASOLINE EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING

Engine(2007 - 2008)	2.7/3.8L GASOLINE GEN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	2.7/3.8L GASOLINE LEAD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	J2.9 WGT(DIESEL)C/RAIL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.ECU INITIALIZATION
	J2.9 VGT(DIESEL)C/RAIL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.ECU INITIALIZATION
AT(2007-2008)	TCU 2.7/3.8L (GASOLINE)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	TCU 2.9 WGT(DIESEL)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	TCU 2.9 VGT(DIESEL)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
ABS(2007-2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		1.SOLENOID VALVE TEST 2.STEERING ANGLE SENSOR 3.VARIANT CODING
SRS(2007-2008)	LONG BODY AIRBAG	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	SHORT BODY AIRBAG	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
AC(2007-2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

FUEL(2007-2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	v			
POWER SLIDING / TAIL GATE	POWER SLIDING -LH	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	POWER SLIDING -RH	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	POWER TAIL GATE	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
BODY CONTROL MODULE(2007-2008)	IN PANEL MODULE			<i>data</i>				
	FRONT AREA MODULE			<i>data</i>				
	REAR AREA MODULE			<i>data</i>				
	DRIVER DOOR MODULE			<i>data</i>				
	ASSIST DOOR MODULE			<i>data</i>				
	INTEGRATED MEM SEAT			<i>data</i>				
Engine(2006)	2.7/3.8L GASOLINE		<i>err. Code</i>	<i>data</i>				1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	J2.9 WGT(DIESEL) C/RAIL		<i>err. Code</i>					1.ECU INITIALIZATION
	J2.9 VGT(DIESEL) C/RAIL		<i>err. Code</i>					1.ECU INITIALIZATION

AT(2006)	TCU 2.7/3.8L(GASOLINE)		<i>err. Code</i>					
	TCU 2.9 WGT(DIESEL)		<i>err. Code</i>					
	TCU 2.9 VGT(DIESEL)		<i>err. Code</i>					
ABS(2006)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		1.SOLENOID VALVE TEST 2.STEERING ANGLE SENSOR 3.VARIANT CODING
SRS(2006)			<i>err. Code</i>					
A/C(2006)			<i>err. Code</i>					
FUEL FIRED HEATER(2006)			<i>err. Code</i>					
POWER SLIDING / TAIL GATE(2006)	POWER SLIDING – LH		<i>err. Code</i>					
	POWER SLIDING – RH		<i>err. Code</i>					
	POWER TAIL GATE		<i>err. Code</i>					
BODY CONTROL MODULE(2006)	IN PANEL MODULE		<i>err. Code</i>					
	FRONT AREA MODULE		<i>err. Code</i>					
	REAR AREA MODULE		<i>err. Code</i>					

IMDOLL(2000)	DRIVER DOOR MODULE		<i>err. Code</i>					
	ASSIST DOOR MODULE		<i>err. Code</i>					
	INTEGRATED MEM SEAT		<i>err. Code</i>					
Engine	3.5L GASOLINE M/EAST (2003-04)		<i>err. Code</i>	<i>data</i>	√			
	2.5L V6 EURO-III		<i>err. Code</i>	<i>data</i>	√			
	2.5L GASOLINE(EUROPE) KV6(1998-2004)		<i>err. Code</i>	<i>data</i>	√			
	2.4/2.5L GASOLINE(GEN) KV6(1998-2004)		<i>err. Code</i>	<i>data</i>	√			
	2.9L DIESEL C/RAIL (2002 -04)		<i>err. Code</i>	<i>data</i>	√			
	3.0L DIESEL(EUROPE) J3TCI (1998-2004)		<i>err. Code</i>					
	3.0L DIESEL(GEN) J3TCI (1998-2004)		<i>err. Code</i>					
AT	3.5L GASOLINE M/EAST (2003-04)		<i>err. Code</i>	<i>data</i>	√			

	GASOLINE (2002 -04)		<i>err. Code</i>	<i>data</i>	√			
	DIESEL (2002 -04)		<i>err. Code</i>	<i>data</i>	√			
	TCU(GENERAL) GAS (1998-2001)		<i>err. Code</i>	<i>data</i>	√			
	TCU(EUROPE) GAS (1998 -2001)		<i>err. Code</i>	<i>data</i>	√			
	TCU(GENERAL) DIESEL (1998-2001)		<i>err. Code</i>	<i>data</i>				
	TCU(EUROPE) DIESEL (1998-2001)		<i>err. Code</i>	<i>data</i>				
ABS	ABS(2002-04)		<i>err. Code</i>	<i>data</i>	√	√		
	ABS EURO -II(2002-04)		<i>err. Code</i>	<i>data</i>	√	√		
	ABS C/RAIL(2002 -04)		<i>err. Code</i>	<i>data</i>	√	√		
	ABS(EUROPE) (1998 -2001)		<i>err. Code</i>	<i>data</i>	√	√		
	ABS(GENERAL) GAS (1998 -2001)		<i>err. Code</i>	<i>data</i>	√	√		

	ABS(GENERAL) DIESEL (1998-2001)		<i>err. Code</i>	<i>data</i>	√	√		
IMMBILIZER	2002~2004			<i>data</i>				01.PASSWORD TEACHING/CHANGING 02.TEACHING 03.NEUTRAL MODE 04.LIMP HOME MODE
	2006~2008			<i>data</i>				01.SMARTRA NEUTRAL 02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.NEUTRAL MODE 05.LIMP HOME MODE
SRS	(2002-2004)		<i>err. Code</i>					
	A/BAG(Europe) (1998 -2001)		<i>err. Code</i>					
	A/BAG(GENERAL) (1998 -2001)		<i>err. Code</i>					
KIA RETONA								
Engine(ALL Year)	2.0L GASOLINE		<i>err. Code</i>	<i>data</i>				
	2.0L DIESEL RF -TCI		<i>err. Code</i>	<i>data</i>	√			

AT(ALL Year)			<i>err. Code</i>	<i>data</i>				
ABS(ALL Year)			<i>err. Code</i>	<i>data</i>	√			
KIA JOICE								
Engine(ALL Year)	2.0L GASOLINE EURO -III		<i>err. Code</i>	<i>data</i>	√			
ABS(ALL Year)			<i>err. Code</i>	<i>data</i>	√	√		
SRS(ALL Year)			<i>err. Code</i>	<i>data</i>				
KIA TOWNER								
KIA PREGIO								
Engine(2002 -04)			<i>err. Code</i>	<i>data</i>	√			
KIA FRONTIER								
Engine(2002 -04)			<i>err. Code</i>	<i>data</i>	√			
KIA SORENTO								
	UNLEAD 3.3/3.8L EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	UNLEAD 3.3/3.8L GEN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING

Engine(2007 - 2008)	LEAD 3.3/3.8L ALL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	2.5 DIESEL(CAN)EURO -4	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.INJECTOR CORRECTION 2.COMPONENT CHANGE ROUTINE 3.ENGINE TEST FUNCTION
	2.5 DIESEL(KWP)EURO -4	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	2.5 DIESEL EURO -3	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.INJECTOR CORRECTION 2.ENGINE TEST FUNCTION
AT(2007-2008)	GASOLINE(CAN) BOSCH	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	GASOLINE(KWP) BOSCH	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	A2.5L DIESEL JATCO	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
ABS(2007-2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		1.SOLENOID VALVE TEST 2.STEERING ANGLE SENSOR 3.VARIANT CODING
SRS(2007-2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
AC(2007-2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

EPS(2007-2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
4WD(2007-2008)		<i>Info</i>	<i>err. Code</i>					
FUEL(2007-2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
BODY CONTROL MODULE(2007~2008)		<i>Info</i>		<i>data</i>	√			
SMK(2007~2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
Engine(2006)	3.3L/3.8L		<i>err. Code</i>					
	2.5L DIESEL(CAN) EURO -4		<i>err. Code</i>					
	2.5L DIESEL(KWP) EURO -4		<i>err. Code</i>					
	2.5L DIESEL EURO -3		<i>err. Code</i>					
AT(2006)	GASOLINE (CAN) BOSCH		<i>err. Code</i>					
	GASOLINE (KWP) BOSCH		<i>err. Code</i>					
	A2.5L DIESEL JATCO		<i>err. Code</i>					
ABS(2006)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

SRS(2006)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
A/C(2006)								
ELEC. POWER STEERING(2006)								
4WD(2006)								
FUEL FIRED HEATER(2006)								
Engine(2003 -05)	ENGINE DIESEL(A -ENG)		<i>err. Code</i>	<i>data</i>	√			1.ENGINE TEST FUNCTION 2.INJECTION CORRECTION
	3.5L V6 GASOLINE ALL		<i>err. Code</i>	<i>data</i>	√			1.IDLE RPM ADJUST MODE
	2.4L GASOLINE UNLEAD		<i>err. Code</i>	<i>data</i>	√			
	2.4L GASOLINE LEAD		<i>err. Code</i>	<i>data</i>	√			
AT(2003-04)	AUTO.TRANSAXLE(4 GEARS)		<i>err. Code</i>	<i>data</i>	√			
	AUTO.TRANSAXLE(5 GEARS)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
ABS(2003-04)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		

SRS(2003-04)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
ELEC. POWER STEERING(2003 - 04)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
IMMBILIZER	2003~2006			<i>data</i>				01.PASSWORD TEACHING/CHANGING 02.TEACHING 03.NEUTRAL MODE 04.LIMP HOME MODE
	2007~2008			<i>data</i>				01.SMARTRA NEUTRAL 02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.NEUTRAL MODE 05.LIMP HOME MODE
4WD(2003-04)			<i>err. Code</i>					
FUEL FIRED HEATER(2003 - 04)			<i>err. Code</i>	<i>data</i>	v			
KIA OPIRUS								

Engine(2009)	GASOLINE EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	GASOLINE EOBD KWP	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	GASOLINE GEN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	GASOLINE GEN KWP	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	GASOLINE LEAD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	GASOLINE LEAD KWP	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
AT(2009)	GASOLINE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	GASOLINE KWP		<i>err. Code</i>	<i>data</i>	√			

ABS(2009)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
SRS(2009)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
IMMBILIZER	2004~2005			<i>data</i>				01.PASSWORD TEACHING/CHANGING
	2007~2009			<i>data</i>				01.SMARTRA NEUTRAL 02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.NEUTRAL MODE 05.LIMP HOME MODE
BCM(2009)	BODY CONTROL MODULE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	DRIVER POWER WINDOW		<i>err. Code</i>	<i>data</i>	√			
	PASSENGER POWER WINDOW		<i>err. Code</i>	<i>data</i>	√			
	DRIVER POWER SEAT		<i>err. Code</i>	<i>data</i>	√			
	TILT & TELESCOPE		<i>err. Code</i>	<i>data</i>	√			
SMART KEY SYSTEM(2009)	SMART KEY UNIT	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	PDM DIAGNOSTIC MODE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

PERSONAL ID. CARD(2009)	INTERFACE UNIT(IFU)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	SMART KEY UNIT(PIC)		<i>err. Code</i>	<i>data</i>	√			
FULL AUTOA/C(2009)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
ELEC. POWER STEERING(2009)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
ELEC. CONTROL SUSPENTION(2009)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
AHLS(2009)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
ENGINE CONTROL (2007~2008)			<i>err. Code</i>					1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
Engine(2004~2005)	3.5L V6 EOBD		<i>err. Code</i>	<i>data</i>	√			
	3.5L V6 GEN		<i>err. Code</i>	<i>data</i>	√			
	2.7L		<i>err. Code</i>					
	2 007		<i>err. Code</i>					
AT	(2004~2005)		<i>err. Code</i>	<i>data</i>	√			
	2 007		<i>err. Code</i>					

ABS/TCS/ESP (2004~2007)			<i>err. Code</i>	<i>data</i>	√			
SRS	(2004~2005)		<i>err. Code</i>	<i>data</i>				
	2 007		<i>err. Code</i>					
BODY CONTROL MODULE(2004~2007)	BODY CONTROL MODULE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	DRIVER POWER WINDOW		<i>err. Code</i>	<i>data</i>	√			
	PASSENGER POWER WINDOW		<i>err. Code</i>	<i>data</i>	√			
	DRIVER POWER SEAT		<i>err. Code</i>	<i>data</i>	√			
	TILT & TELESCOPE		<i>err. Code</i>	<i>data</i>	√			
	DIAGNOSE ECM TOTALY		<i>err. Code</i>					
A/C			<i>err. Code</i>	<i>data</i>	√			
ELEC. POWER STEERING			<i>err. Code</i>					
ELEC. CONTROL SUSPENSION			<i>err. Code</i>					
AHLS		<i>Info</i>	<i>err. Code</i>	<i>data</i>				

SMART KEY	IFU	<i>Info</i>		<i>data</i>	√			
KIA SPECTRA								
Engine(All Year)	Eng. 1.5L/1.6(Non Immo)		<i>err. Code</i>	<i>data</i>				
	Eng. 1.5L/1.6(W/Immo)		<i>err. Code</i>	<i>data</i>				
	Eng. 1.5L/1.6 Lead		<i>err. Code</i>	<i>data</i>				
AT(All Year)			<i>err. Code</i>	<i>data</i>				
ABS(All Year)			<i>err. Code</i>	<i>data</i>	√			
SRS(All Year)			<i>err. Code</i>					
KIA CREDOS								
Engine(All Year)	CREDOS 1.8 DOHC ENG		<i>err. Code</i>	<i>data</i>	√			
	CREDOS 2.0 SOHC ENG		<i>err. Code</i>	<i>data</i>	√			
	CREDOS 2.0 DOHC ENG		<i>err. Code</i>	<i>data</i>	√			
	CREDOS 1.8 LPG ENG		<i>err. Code</i>	<i>data</i>	√			
	CREDOS 2.0 LPG ENG		<i>err. Code</i>	<i>data</i>	√			
	CREDOS II 1.8 DOHC ENG		<i>err. Code</i>	<i>data</i>	√			

	CREDOS II 2.0 SOHC ENG		<i>err. Code</i>	<i>data</i>	v			
	CREDOS II 2.0 DOHC ENG		<i>err. Code</i>	<i>data</i>	v			
	CREDOS II V6 ENG		<i>err. Code</i>	<i>data</i>				
AT(All Year)	CREDOS 1.8 LPG AT							
	CREDOS 2.0 LPG AT							
	CREDOS II 1.8 DOHC AT		<i>err. Code</i>	<i>data</i>				
	CREDOS II 2.0 SOHC AT		<i>err. Code</i>	<i>data</i>				
	CREDOS II 2.0 DOHC AT		<i>err. Code</i>	<i>data</i>				
	CREDOS II V6 AT		<i>err. Code</i>	<i>data</i>				
SRS(All Year)	CREDOS 1.8 DOHC SRS		<i>err. Code</i>	<i>data</i>				
	CREDOS 2.0 SOHC SRS		<i>err. Code</i>	<i>data</i>				
	CREDOS 2.0 DOHC SRS		<i>err. Code</i>	<i>data</i>				
	CREDOS II 1.8 DOHC SRS		<i>err. Code</i>	<i>data</i>				
	CREDOS II 2.0 SOHC SRS		<i>err. Code</i>	<i>data</i>				

	CREDOS II 2.0 DOHC SRS		<i>err. Code</i>	<i>data</i>				
	CREDOS II V6 SRS		<i>err. Code</i>	<i>data</i>				
KIA CARSTAR								
Engine(All Year)	CARSTAR FBM(LPG) ENG		<i>err. Code</i>	<i>data</i>				
ABS(All Year)	CARSTAR DOHC ABS		<i>err. Code</i>	<i>data</i>	v			
	CARSTAR FBM(LPG) ABS		<i>err. Code</i>	<i>data</i>	v			
SRS(All Year)	CARSTAR DOHC SRS		<i>err. Code</i>	<i>data</i>				
	CARSTAR FBM(LPG) SRS		<i>err. Code</i>	<i>data</i>				
KIA K2500								
Engine(2008)	J2.9 WGT C/RAIL	<i>Info</i>	<i>err. Code</i>	<i>data</i>				1.ECU INITIALIZATION
TCU 2.9 WGT(2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
IMMBILIZER(2008)				<i>data</i>				01.SMARTRA NEUTRAL 02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.NEUTRAL MODE 05.LIMP HOME MODE

Engine(2007)	2.5L Diesel Eng. (4D56 TCI)		<i>err. Code</i>	<i>data</i>	√			
Engine(2006)	2.5L Diesel Eng. (4D56 TCI)		<i>err. Code</i>	<i>data</i>	√			
Engine(2004~2005)	2.5L Diesel Eng. (4D56 TCI)		<i>err. Code</i>	<i>data</i>	√			
Engine(2003)	2.5L Diesel Eng. (4D56 TCI)		<i>err. Code</i>	<i>data</i>	√			
Engine(2002)	2.5L Diesel Eng. (4D56 TCI)		<i>err. Code</i>	<i>data</i>	√			

KIA PICANTO (MORNING)

Engine(2008)	1.1L VGT DIESEL CAN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.ENGINE TEST FUNCTION 2.INJECTION CORRECTION
	1.0L/1.1L EOBD CAN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	1.0L/1.1L EOBD KWP	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	1.0L/1.1L GEN CAN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	1.0L/1.1L GEN KWP	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

	1.0L/1.1L LEAD CAN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	1.0L/1.1L LEAD KWP	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.IDLE CO ADJUSTMENT
AT(2008)	GASOLINE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
	DIESEL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
ABS/ESP(2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
FULL AUTO A/C(2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
IMMOBILIZER	2 008			<i>data</i>				01.SMARTRA NEUTRAL 02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.NEUTRAL MODE 05.LIMP HOME MODE
SRS(2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
ELEC. POWER STEERING(2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
Engine(2006~20	1.1L VGT DIESEL CAN		<i>err. Code</i>					1.ENGINE TEST FUNCTION 2.INJECTION CORRECTION

07)

Created with

 **nitro**^{PDF} professional

download the free trial online at nitropdf.com/professional

011	1.1L VGT DIESEL KWP		<i>err. Code</i>					1.ENGINE TEST FUNCTION 2.INJECTION CORRECTION
AT(2006~2007)	GASOLINE		<i>err. Code</i>	<i>data</i>				
	DIESEL		<i>err. Code</i>					
ABS(2006~2007)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
SRS(2006~2007)		<i>Info</i>	<i>err. Code</i>				√	
ELEC. POWER STEERING(2006~2007)			<i>err. Code</i>					1.EPS TYPE RECOGNITION
Engine(2004~2005)	1.0L/1.1L SOHC EOBD		<i>err. Code</i>	<i>data</i>				
	1.0L/1.1L SOHC GEN		<i>err. Code</i>	<i>data</i>				
	1.0L/1.1L SOHC Lead		<i>err. Code</i>	<i>data</i>				1.IDLE CO ADJUSTMENT
AT(2004~2005)			<i>err. Code</i>	<i>data</i>				

IMMOBILIZER	2004~2007			<i>data</i>				01.SMARTRA NEUTRAL 02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.NEUTRAL MODE 05.LIMP HOME MODE
ABS(2004~2005)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
SRS(2004~2005)		<i>Info</i>	<i>err. Code</i>				√	
KIA CERATO (SPECTRA)								
Engine(2007~2008)	UNLEAD 2.0L GEN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
	UNLEAD 2.0L EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
	LEAD 2.0L ALL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
	LEAD 1.6L GEN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
	LEAD 1.6L EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES

	LEAD 1.6L ALL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESETTING ADAPTIVE VALUES
	DIESEL VGT	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.ENGINE TEST FUNCTION 2.INJECTION CORRECTION
AT(2007~2008)	1.6 GASOLINE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	2.0 GASOLINE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	1.6 DIESEL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
ABS(2007~2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
SRS(2007~2008)			<i>err. Code</i>	<i>data</i>				
AC(2007~2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
Engine(2004~2005)	2.0L/1.6L GASOLINE		<i>err. Code</i>					
	1.6L DIESEL(VGT) EURO -4		<i>err. Code</i>					
	2.0L Diesel Eng. All	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.ENGINE TEST FUNCTION
	1.6L DOHC EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	1.6L DOHC general	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

	1.6L DOHC lead -content	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.IDLE CO ADJUSTMENT
	2.0L DOHC (+CVVT) EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESTTING ADAPTIVE VALUES 2.VERSION CONFIGURATION
	2.0L DOHC (-CVVT) EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESTTING ADAPTIVE VALUES 2.VERSION CONFIGURATION
	2.0L DOHC (+CVVT) general	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESTTING ADAPTIVE VALUES 2.VERSION CONFIGURATION
	2.0L DOHC (-CVVT) general	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESTTING ADAPTIVE VALUES 2.VERSION CONFIGURATION
	2.0L DOHC (+CVVT) lead -content	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESTTING ADAPTIVE VALUES 2.VERSION CONFIGURATION
	2.0L DOHC (-CVVT) lead -content	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESTTING ADAPTIVE VALUES 2.VERSION CONFIGURATION
Engine(2005)	1.5L DIESEL ALL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.ENGINE TEST FUNCTION 2.INJECTION CORRECTION

AT(2004~2007)	1.6LDOHC ALL		<i>err. Code</i>	<i>data</i>	√			
	2.0LDOHC ALL		<i>err. Code</i>	<i>data</i>	√			
ABS(2004~2007)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
SRS(2004~2007)		<i>Info</i>	<i>err. Code</i>				√	
IMMOBILIZER	2004~2008			<i>data</i>				01.SMARTRA NEUTRAL 02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.NEUTRAL MODE 05.LIMP HOME MODE
A/C(2007)			<i>err. Code</i>					
KIA CEE'D								
Engine(2007)	BETA 2.0L	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESTTING ADAPTIVE VALUES
	GAMMA 1.4L/1.6L	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.RESTTING ADAPTIVE VALUES
	U 1.6L DIESEL (- CPF)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.ENGINE TEST FUNCTION 2.INJECTION CORRECTION

	U 1.6L DIESEL (+ CPF)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	v			1.CPF SERVICE REGENERATION 2.INJECTOR CORRECTION 3.COMPONENT CHANGE ROUTINE 4.ENGINE TEST FUNCTION
	2.0L DIESEL(CAN) EURO -4	<i>Info</i>	<i>err. Code</i>	<i>data</i>	v			1.CPF SERVICE REGENERATION 2.INJECTOR CORRECTION 3.COMPONENT CHANGE ROUTINE 4.ENGINE TEST FUNCTION
AT(2007)	1.4/1.6 GASOLINE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	v			
	2.0 GASOLINE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	v			
ABS(2007)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	v	v		1.SOLENOID VALVE TEST 2.VARIANT CODING
SRS(2007)		<i>Info</i>	<i>err. Code</i>				v	
A/C(2007)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	v			
TPMS		<i>Info</i>	<i>err. Code</i>	<i>data</i>	v			

BODY CONTROL MODULE(2007)		<i>Info</i>		<i>data</i>	√			
IMMOBILIZER				<i>data</i>				01.SMARTRA NEUTRAL 02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.NEUTRAL MODE 05.LIMP HOME MODE
ELEC. POWER STEERING(2007)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
KIA SOUL(2009)								
ENGINE CONTROL	UNLEAD 1.6L GEN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1、 RESETTING ADAPTIVE VALUES
	UNLEAD 1.6L EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1、 RESETTING ADAPTIVE VALUES
	LEAD 1.6L ALL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1、 RESETTING ADAPTIVE VALUES 2、 IDLE CO ADJUSTMENT
	2.0L CVVT EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1、 RESETTING ADAPTIVE VALUES

	2.0L CVVT GEN	Info	err. Code	data	√			1、 RESETTING ADAPTIVE VALUES
	2.0L CVVT LEAD	Info	err. Code	data	√			1、 RESETTING ADAPTIVE VALUES 2、 IDLE CO ADJUSTMENT
	1.6L VGT EURO5 CPF-	Info	err. Code	data	√			1、 INJECTION CORRECTION
	1.6L VGT EURO5 CPF+	Info	err. Code	data	√			1、 INJECTION CORRECTION
AT	GAMMA 1.6/U2 1.6 CAN	Info	err. Code	data	√			1、 RESETTING AUTO T/A VALUES
	BETA GASOLINE 2.0 CAN	Info	err. Code	data	√			1、 RESETTING AUTO T/A VALUES
ABS/ESP		Info	err. Code	data	√	√		1、 SAS SENSOR ZERO SETTING
SRS								
BCM								
EPS								

IMMOBILIZER				<i>data</i>				02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.IMMOBILIZER RESET 05.LIMP HOME MODE 06.SMARTRA NEUTRAL
KIA MOHAVE/B								
ENGINE (2008)	UNLEAD 3.8L EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	UNLEAD 3.8L GEN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	LEAD 3.8L ALL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.PCM AUTO DETECTION RESET 2.PCM LOCK(MEC) SETTING
	UNLEAD 4.6L EOBD	<i>Info</i>	<i>err. Code</i>	<i>data</i>				1.RESETTING ADAPTIVE VALUES
	3.0L VGT EURO4 DIESEL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			1.INJECTOR CORRECTION 2.COMPONENT CHANGE ROUTINE 3.ENGINE TEST FUNCTION

AT(2008)	TCU 3.8L	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	ZF TCU	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
ABS(2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		1.STEERING ANGLE SENSOR 2.VARIANT CODING
IMMOBILIZER				<i>data</i>				01.SMARTRA NEUTRAL 02.PASSWORD TEACHING/CHANGING 03.TEACHING 04.NEUTRAL MODE 05.LIMP HOME MODE
SRS-AIRBAG(2008)		<i>Info</i>	<i>err. Code</i>					1.PASS.AIRBAG REALTIME INFO. 2.CRASHING INFORMATION
KIA ORREGO								
ELEC.POWER STEERING(2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
IN PANEL MODULE(2008)	IPM	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	FAM	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	RAM	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

	DDM	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	ADM	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
ELEC.CONTROL SUSPENTION(2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
4WD(2008)	TOD(EPS)	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	TOD(ABS)	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	4WD(EST-MANUAL)	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
IMMOBILIZER				<i>data</i>				
FULL AUTOAIR		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
SMART KEY SYSTEM(2008)	SMART KEY UNIT	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	PDM DIAGNOSTIC MODE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
KIA YN								
ENG(2007~2008)	GAMMA 1.4L/1.6L	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
AT(2007~2008)	1.4/1.6L GASOLINE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
AC(2007~2008)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

EPS(2007~2008)		Info	err. Code	data				
KIA SORENTO R(XM)								
ENG(2009)	2.4 THETA 2	Info	err. Code	data	√			
	3.5 LAMDA 2	Info	err. Code	data	√			
AT		Info	err. Code	data	√			
ABS			err. Code	data	√			
AC		Info	err. Code	data	√			
EPS		Info	err. Code	data				
SRS		Info	err. Code	data				
BCM		Info	err. Code	data	√			
SMART KEY SYSTEM	SMART KEY UNIT	Info	err. Code	data	√			
	PDM(POWER DISTRIBUTIN)	Info	err. Code	data	√			
AHLS		Info	err. Code	data				
4WD			err. Code	data				

TPMS		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
Korea								
KIA PRIDE(~04)								
Engine	NEW STYLE ENGINE SIEMENS		<i>err. Code</i>	<i>data</i>				
KIA PRIDE(05~)								
Engine	1.6 CVVT		<i>err. Code</i>	<i>data</i>	√			
	1.4 DOHC		<i>err. Code</i>	<i>data</i>	√			
	U 1.5L VGT DIESEL		<i>err. Code</i>	<i>data</i>	√			
AT			<i>err. Code</i>	<i>data</i>	√			
ABS		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
HYBRID	Hybrid Control(HCU)		<i>err. Code</i>	<i>data</i>	√			
	Motor control(MCU)		<i>err. Code</i>	<i>data</i>	√			
	Battery Control(BMS)		<i>err. Code</i>	<i>data</i>	√			
SRS		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
AC		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

EPS		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	AT		<i>err. Code</i>	<i>data</i>				
KIA VISTO								
Engine	ENGINE 0.8 SOHC		<i>err. Code</i>	<i>data</i>	√			
ABS			<i>err. Code</i>	<i>data</i>	√	√		
SRS			<i>err. Code</i>	<i>data</i>				
KIA MORNING								
Engine	ENGINE 1.0 SOHC		<i>err. Code</i>	<i>data</i>				
AT		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
ABS		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
SRS		<i>Info</i>	<i>err. Code</i>				√	
KIA AVELLA								
AT			<i>err. Code</i>					
ABS			<i>err. Code</i>	<i>data</i>				
KIA RIO								
Engine	ENGINE 1.3/1.5 SIEMENS		<i>err. Code</i>	<i>data</i>				

AT			<i>err. Code</i>	<i>data</i>				
ABS			<i>err. Code</i>	<i>data</i>	√			
SRS			<i>err. Code</i>					
KIA RIO SF								
Engine	ENGINE 1.3/1.5 SIEMENS		<i>err. Code</i>	<i>data</i>				
AT			<i>err. Code</i>	<i>data</i>				
ABS		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
SRS			<i>err. Code</i>					
KIA ELAN								
Engine	ENGINE 1.8 DOHC BOSCH		<i>err. Code</i>	<i>data</i>	√			
SRS			<i>err. Code</i>					
KIA SEPHIA								
AT			<i>err. Code</i>					
SRS			<i>err. Code</i>					
KIA SEPHIA II								
Engine	ENGINE 1.5 SOHC SIEMENS		<i>err. Code</i>	<i>data</i>				

	ENGINE 1.5 DOHC BOSCH		<i>err. Code</i>	<i>data</i>				
	ENGINE 1.8 BOSCH		<i>err. Code</i>	<i>data</i>				
AT			<i>err. Code</i>	<i>data</i>				
ABS			<i>err. Code</i>	<i>data</i>	√			
SRS			<i>err. Code</i>					
KIA SPECTRA(WING)								
Engine	ENGINE 1.8 BOSCH		<i>err. Code</i>	<i>data</i>				
	ENGINE 1.5 BOSCH		<i>err. Code</i>	<i>data</i>				
AT			<i>err. Code</i>	<i>data</i>				
ABS			<i>err. Code</i>	<i>data</i>	√			
SRS			<i>err. Code</i>					
KIA SHUMA								
Engine	ENGINE 1.5 SOHC SIEMENS		<i>err. Code</i>	<i>data</i>				
	ENGINE 1.5 DOHC BOSCH		<i>err. Code</i>	<i>data</i>				
	ENGINE 1.8 BOSCH		<i>err. Code</i>	<i>data</i>				

AT			<i>err. Code</i>	<i>data</i>				
ABS			<i>err. Code</i>	<i>data</i>	√			
SRS			<i>err. Code</i>					
KIA CERATO								
Engine	ENGINE 2.0 CVVT SIEMENS	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	Diesel ENG. 1.6LVGT	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	Engine 1.5/1.6 CVVT	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	Engine 2.0L(MT)	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	Engine 2.0L(AT)	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
AT	1.5 IMPROVED TYPE (INTEGRATION)		<i>err. Code</i>	<i>data</i>	√			
	1.6 L(new)	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	2.0 L(new)	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	Diesel	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
ABS		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

	F/L new	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	SRS old	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
AC		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
KIA CARENS								
Engine(2006 -)	LPI(EMS ECU)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	LPI(IFB ECU)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	DIESEL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
AT(2006-)	LPI	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	DIESEL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
ABS(2006-)			<i>err. Code</i>	<i>data</i>	√			
SRS(2006-)		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
A/C(2006-)		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
BODY CONTROL MODULE(2006-)		<i>Info</i>		<i>data</i>	√			
Engine	ENGINE 1.8 BOSCH		<i>err. Code</i>	<i>data</i>				

	ENGINE 1.8 LPG MODERN AUTONET		<i>err. Code</i>	<i>data</i>	√			
	ENGINE 2.0 LPG MODERN AUTONET		<i>err. Code</i>	<i>data</i>	√			
AT			<i>err. Code</i>	<i>data</i>				
ABS			<i>err. Code</i>	<i>data</i>	√			
SRS			<i>err. Code</i>					
KIA CARENS II								
Engine	ENGINE 1.8 LPG MODERN AUTONET		<i>err. Code</i>	<i>data</i>	√			
	ENGINE 2.0 LPG MODERN AUTONET		<i>err. Code</i>	<i>data</i>	√			
	ENGINE 1.8		<i>err. Code</i>	<i>data</i>				
	ENGINE 2.0 CVVT SIEMENS		<i>err. Code</i>	<i>data</i>	√			
AT	1.8LPG/1.8 GASOLINE		<i>err. Code</i>	<i>data</i>				
	2.0LPG/2.0 GASOLINE		<i>err. Code</i>	<i>data</i>	√			
ABS		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		

SRS		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
KIA CREDOS								
Engine	ENGINE 1.8 DOHC BOSCH		<i>err. Code</i>	<i>data</i>	√			
	ENGINE 2.0 SOHC BOSCH		<i>err. Code</i>	<i>data</i>	√			
	ENGINE 2.0 DOHC BOSCH		<i>err. Code</i>	<i>data</i>	√			
SRS			<i>err. Code</i>	<i>data</i>				
KIA CREDOS II								
Engine	ENGINE 1.8 DOHC BOSCH		<i>err. Code</i>	<i>data</i>	√			
	ENGINE 2.0 SOHC BOSCH		<i>err. Code</i>	<i>data</i>	√			
	ENGINE 2.0 DOHC BOSCH		<i>err. Code</i>	<i>data</i>	√			
SRS			<i>err. Code</i>	<i>data</i>				
KIA OPTIMA								
Engine	ENGINE 1.8/2.0 MELCO		<i>err. Code</i>	<i>data</i>	√			
	ENGINE 1.8 DOHC SIEMENS	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	ENGINE 2.5 V6 SIEMENS		<i>err. Code</i>	<i>data</i>	√			

	ENGINE 2.0 LPG SIRIUS ENGINE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	ENGINE 2.0 LPG BETA ENGINE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
AT	1.8/2.0/2.5 ALL		<i>err. Code</i>	<i>data</i>	√			
	CVT	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
ABS	MANDO TYPE		<i>err. Code</i>	<i>data</i>	√			
	BOSCH TYPE		<i>err. Code</i>	<i>data</i>	√			
SRS			<i>err. Code</i>	<i>data</i>				
KIA OPTIMA (REGAL)								
Engine	ENGINE 1.8 DOHC SIEMENS	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	ENGINE 2.0 DOHC MELCO		<i>err. Code</i>	<i>data</i>	√			
	ENGINE 2.5 V6 SIEMENS		<i>err. Code</i>	<i>data</i>	√			
	ENGINE 2.0 LPG BETA ENGINE	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
AT	2.0		<i>err. Code</i>	<i>data</i>	√			

	1.8/2.5 SIEMENS	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	CVT	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
ABS	BOSCH TYPE		<i>err. Code</i>	<i>data</i>	√			
SRS		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
KIA SPORTAGE (-97)								
Engine	ENGINE 2.0 BOSCH		<i>err. Code</i>	<i>data</i>	√			
KIA SPORTAGE (98-03)								
Engine	ENGINE 2.0 BOSCH		<i>err. Code</i>	<i>data</i>				
AT			<i>err. Code</i>	<i>data</i>				
ABS			<i>err. Code</i>	<i>data</i>	√	√		
KIA SPORTAGE (04)								
Engine	2.0 WGT EURO 3 DIESEL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	2.0L CVVT SIEMENS	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	DIESEL		<i>err. Code</i>	<i>data</i>	√			
AT	2.0L DIESEL MELCO	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

	2.0L DIESEL BOSCH	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	2.0L CVVT SIEMENS	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
ABS/TCS/ESP		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
A/C		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
4WD		<i>Info</i>	<i>err. Code</i>					
	WIPER SENSOR(VVALID)	<i>Info</i>		<i>data</i>	√			
	WIPER SENSOR(INVALID)	<i>Info</i>		<i>data</i>	√			

KIA SORENTO

Engine	2.5L CRDI DIESEL WGT(~03)		<i>err. Code</i>	<i>data</i>	√			
	2.5L CRDI DIESEL WGT(04~)		<i>err. Code</i>	<i>data</i>	√			
	2.5L CRDI DIESEL WGT(05~)		<i>err. Code</i>	<i>data</i>	√			
	3.5 GASOLINE		<i>err. Code</i>	<i>data</i>	√			
	2.5L DIESEL(EURO3) CAN	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	2.5L DIESEL(EURO3) KWP		<i>err. Code</i>	<i>data</i>	√			

AT	Automatic transmission(4S)		<i>err. Code</i>	<i>data</i>	√			
ABS		<i>Info</i>	<i>err. Code</i>	<i>data</i>	√	√		
SRS		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
ELEC. POWER STEERING		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
4WD	4WD(TOD-AUTO)		<i>err. Code</i>					
FUEL FIRED HEATER			<i>err. Code</i>	<i>data</i>	√			
KIA CARNIVAL/ CARNIVAL II								
Engine	ENGINE 3.0 DIESEL		<i>err. Code</i>					
	ENGINE 2.5 LPG		<i>err. Code</i>	<i>data</i>	√			
AT			<i>err. Code</i>	<i>data</i>	√			
ABS			<i>err. Code</i>	<i>data</i>	√	√		
SRS			<i>err. Code</i>					
KIA GRAND CARNIVAL								
Engine	KJ 2.9 CRDI WGT DIESEL		<i>err. Code</i>	<i>data</i>	√			
	KJ 2.9 CRDI VGT DIESEL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			

	2.7 LPI(EMS ECU)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	2.7 LPI(IFB ECU)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
AT	KJ 2.9 CRDI VGT DIESEL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	KJ 2.9 CRDI WGT DIESEL	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	2.7 LPI		<i>err. Code</i>	<i>data</i>	√			
ABS			<i>err. Code</i>	<i>data</i>	√			
SRS			<i>err. Code</i>				√	
A/C			<i>err. Code</i>	<i>data</i>	√			
KIA POTENTIA								
Engine	ENGINE 2.0 DOHC BOSCH		<i>err. Code</i>					
AT			<i>err. Code</i>					
ABS	ABS 5		<i>err. Code</i>	<i>data</i>				
	ABS/ASR 5(TCS INCLUDED)		<i>err. Code</i>	<i>data</i>				
KIA NEW POTENTIA								
Engine	ENGINE 2.0L(before 2001)		<i>err. Code</i>					

	ENGINE 2.0L(after 2001)		<i>err. Code</i>	<i>data</i>				
	ENGINE 2.5 V6 JAPAN ELECTROMOTION		<i>err. Code</i>	<i>data</i>				
AT			<i>err. Code</i>					
ABS	ABS 5		<i>err. Code</i>	<i>data</i>				
	ABS/ASR 5(TCS INCLUDED)		<i>err. Code</i>	<i>data</i>				
KIA ENTERPRISE								
Engine	ENGINE 2.5 V6		<i>err. Code</i>	<i>data</i>				
	ENGINE 3.0 V6 JAPAN ELECTROMOTION		<i>err. Code</i>	<i>data</i>				
	ENGINE 3.6 V6 JAPAN ELECTROMOTION		<i>err. Code</i>	<i>data</i>				
	ENGINE 2.5 V6 BOSCH(00MY~)		<i>err. Code</i>	<i>data</i>				
AT			<i>err. Code</i>					
ABS	ABS 5		<i>err. Code</i>	<i>data</i>				
	ABS/ASR 5(TCS INCLUDED)		<i>err. Code</i>	<i>data</i>				

SRS			<i>err. Code</i>					
KIA OPIRUS								
Engine	ENGINE 3.0/3.5 ETS MELCO		<i>err. Code</i>	<i>data</i>	√			
	2.7L		<i>err. Code</i>					
	F/L new	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	Old Lamda		<i>err. Code</i>	<i>data</i>	√			
	LPI(EMS ECU)redo car	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
	LPI(EMS ECU) delta	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	LPI(EMS ECU)	<i>Info</i>	<i>err. Code</i>	<i>data</i>				
AT	Old Lamda	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	2.7/3.0/3.5 TCU		<i>err. Code</i>	<i>data</i>	√			
ABS			<i>err. Code</i>	<i>data</i>	√			
SRS			<i>err. Code</i>	<i>data</i>				
A/C			<i>err. Code</i>	<i>data</i>	√			
ELEC. POWER STEERING			<i>err. Code</i>					

ELEC. CONTROL SUSPENSION			<i>err. Code</i>					
AHLS		<i>Info</i>	<i>err. Code</i>	<i>data</i>				
SMART KEY	INTERBASE UNIT (IFU)	<i>Info</i>		<i>data</i>	√			
KIA LOTZE								
Engine	1.8/2.0 & 2.4+ET		<i>err. Code</i>	<i>data</i>	√			
	LPI (EMS ECU)		<i>err. Code</i>	<i>data</i>	√			
	LPI (IFB ECU)		<i>err. Code</i>	<i>data</i>	√			
AT	1.8/2.0 & 2.4+ET		<i>err. Code</i>	<i>data</i>	√			
	Diesel CAN BUS		<i>err. Code</i>	<i>data</i>	√			
ABS			<i>err. Code</i>	<i>data</i>	√			
SRS			<i>err. Code</i>				√	
KIA BONGO III								
Engine	2.5 (TCI)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
	2.9 (COMMON RAIL)	<i>Info</i>	<i>err. Code</i>	<i>data</i>	√			
AT		<i>Info</i>	<i>err. Code</i>	<i>data</i>				

ABS		<i>Info</i>	<i>err. Code</i>	<i>data</i>	v			
-----	--	-------------	------------------	-------------	---	--	--	--

Created with

 **nitro**^{PDF} professional

download the free trial online at nitropdf.com/professional